



CS6509A ADDITIONAL HANDSET REGISTRATION INSTRUCTIONS

This additional handset has been designed to operate with the CS6519A telephone system. Please refer to your CS6519A user's manual for instructions on general functionality.


Package Contents

- CS6509A handset
- Handset charger and power adapter
- NiMH rechargeable battery pack

Setting up Your CS6509A Additional Handset

The position in which you place the CS6509A charger could have an effect on the range and performance of your CS6509A.


1. Plug the mains power cable into the charger base, plug the other end into the mains power wall socket and switch the power on.



NOTE






Ensure the power cord is fed through the slot on the charger so the unit sits flush with the desk.

2. Slide open the battery compartment cover. Plug the battery connector securely into the socket.
3. Place the battery the wires inside the battery compartment.
4. Slide the battery compartment cover towards the center of the handset until it clicks into place.
5. Place the handset in the base station or charger to charge for at least 14 hours..



Registering an Additional Handset

The CS6509A additional handset must be registered to the telephone base before use. To register the additional handset to your CS6519A, follow the instructions below.

1. Press and hold  **HANDSET LOCATOR** on the base station for about five seconds, the base station is entered into registration mode.
2. Press **OK** and  or  to select **REGISTRATION**.
3. Press **OK** and  or  to select the base station to register the handset.
4. Press **OK** and you are requested to enter the 4-digit system PIN.
5. Enter the 4-digit system PIN and press **OK** to confirm and begin registration.

NOTE

If the handset registration is successful, the handset will automatically be allocated the next available handset number. This handset number is shown in the handset display in standby mode.

If you have any problems with your phone, refer to the TROUBLESHOOTING section of your CS6519A User's manual, or call our Customer Service Hotline.